


## Lighttools® Soft Egg Crates® and Stretch Frames®



### Attaching Soft Egg Crates® to a Softbox

Proper placement of your Soft Egg Crate® ensures predictable light control and keeps the product securely attached to your softbox.

- Locate the double stitched corner seams and place two corners of the Soft Egg Crate® **centered** between the two corners of the softbox.

Press the hook and loop fasteners together, using thumb and forefinger.

- Repeat the same procedure on opposite sides of the box.
- Keep the corners of the Soft Egg Crate® **centered** between the corners of the softbox. Using your thumb and forefinger to press the hook and loop fasteners together all the way around the softbox.

### Remove and Store Soft Egg Crates®

- Release the corners of the Soft Egg Crate® from the softbox.
- Drape the Soft Egg Crate® from one corner following the original memory fold.
- Tie the collapsed crate using the hook and loop straps provided.

Lighttools® Soft Egg Crates® work best with

## Stretch Frames®

Stretch Frames® eliminate sag regardless of how much the lightbank is angled downward.

- 100% Efficiency
- One collapsible piece
- Easy to use
- 6 year Warranty

